EZ REMOTE

SAT Power Button
Turn On/Off the satellite receiver

SAT Control Button
Watch Satellite TV Programming

DISH Button
Will access the dish home Interactive TV menu

Menu Button
Press to view the Main Menu

Left/Themes Button
Moves cursor to the Left or views the Themes Menu when in Satellite Mode

Info Button
Displays program information

Channel Down Button
Channels down or Moves the cursor down

Cancel Button
Cancel an action

Recall Button
Returns to previous channel

TV Power Button
Turn On/Off the TV

TV Control Button
Watch off-air TV Programming

Guide Button
Displays the Program Guide and cycles through the Favorite Lists

Channel Up Button
Channels up or Moves the cursor up

Right/Browse Button
Move cursor to the Right or opens the Browse Banner when in Satellite Mode

Select Button
Selects highlighted item on the TV Screen

Volume Button
Press to lower or raise the TV sound

Number Buttons
Used to enter channel numbers, navigating the Interactive Menus, and the letters in Search Menu

Mute Button
Turns TV sound On/Off