7100/7200 REPLACEMENT REMOTE

TV Mode Button
Determines which device the remote will control

SAT Mode Button
Press to set the remote to control another DISH Network Satellite receiver (other than your DishPlayer 7100/7200 model)

TV/Video Button
Press to switch through TV Inputs

Options Button
Opens / closes the Options menu

Volume Button
Press to lower or raise the TV sound

Mute Button
Turns TV sound On/Off

Select Button
Activates highlighted item. When internet textbox is highlighted activates on-screen keyboard* Web TV / MSN TV subscription required

Recall Button
Returns to previous channel

Info Button
Displays program or Web page information* Web TV / MSN TV subscription required

Personal TV/DVR Button
Press to access Personal TV features

Skip Back Button
Skips back 10 seconds in a program when using Personal TV functions

Recover Button
Allows easy recovery back to DISH Network programming and toggles through TV inputs

TV/Web Button
Logs on to the internet. Switches between TV and Web viewing while on the internet* Web TV / MSN TV subscription required

Number Buttons
Enter channels you want to view or enters text in text fields on the internet* Web TV / MSN TV subscription required

Scroll Down Button
Press to scroll screens, TV Listings and Web pages

Power Button(s)
Turns on/off the currently selected device (TV, VCR, etc...)

VCR Mode Button
Determines which device the remote will control

DISHPlayer Aux Mode Button
Press this button to set the remote to control your DishPlayer model 7100/7200

Channel Buttons
Changes channels up or down

Listings Button
Displays TV programming guide

Navigation Buttons
Navigates menus in TV mode and on the Internet* by moving the yellow highlight box Web TV / MSN TV subscription required

Back Button
Quits any active TV menu. Jumps to the last Internet Web page* Web TV / MSN TV subscription required

Enter Button
Displays program banner or activates menu highlighted item

Skip Forward Button
Skips forward 30 seconds in a program when using Personal TV functions

Back, Stop, Pause, Play and Fwd Buttons
Functions Personal TV when in SAT mode, standard operation when in VCR mode

DISH Button
Activates TV Home Interactive menu. Navigates to Web Home while surfing the internet*

PIP Button
Activates the Picture-In-Picture feature. Enables you to view TV programs while browsing the internet* Web TV / MSN TV subscription required

Recent Button
Displays a list of recently visited Web pages or TV channels. Moves the PIP window around the TV screen* Web TV / MSN TV subscription required

Scroll Up Button
Press to scroll screens, TV Listings and Web pages