# DISHPLAYER 7100 REMOTE

**TV /Video Button**
Press to switch through TV Inputs

**Listings Button**
Press to display TV Listings and cycle through Favorites

**PIP Button**
Display WebPIP (TV window) while using the Web

**View Button**
Switch between TV and Web viewing

**Home Button**
Press to display TV Home screen

**Back Button**
Returns to previous screen

**Left Button**
Press to move yellow box or cursor. Also Rewind for PTV. Multiple presses cycle through 4x, 15x, 60x, 300x speeds.

**Down Button**
Move yellow box or cursor. Also 7-second Instant Replay for PTV.

**Recent Button**
Press to display recent channels or web pages

**Mute Button**
Turns TV sound On/Off

**Volume Button**
Press to lower or raise the TV sound

**Number Buttons**
Used to enter channel numbers, navigating the Interactive Menus, and the letters in Search Menu

**Recall Button**
Returns to previous channel

**TV Power Button**
Turns On/Off the TV

**WEBTV Power Button**
Turns On/Off the DISHPlayer

**Info Button**
Press to display TV program or web page information

**TV/WEB Mode Select Button**
Press to select TV or WEBTV mode

**Scroll Button**
Press to scroll screens, TV Listings and Web pages

**Up Button**
Press to move yellow box or cursor. Also 30-second Advance Skip ("commercial skip") for PTV.

**Right Button**
Press to move yellow box or cursor. Also Fast Forward for PTV. Multiple presses cycle through 4x, 15x, 60x, 300x speeds.

**Go Button**
Select highlighted item. Also toggles between Pause and Play for PTV.

**Options Buttons**
Press to display Options panel (includes TV Pause and goes to features)

**Channel Button**
Press to change Satellite or TV channels

**Enter Button**
Press to move WebPIP (TV window) while on the Web; enter a channel number