1.0 IR DEDICATED REMOTE

Browse Button
Press to view the Browse Banner

TV/Video Button
Press to switch through TV Inputs

Mute Button
Turns TV sound On/Off

Volume Button
Press to lower or raise the TV sound

Left Button
Moves cursor to the Left

Select Button
Selects highlighted item on the TV Screen

Info Button
Displays program information

Sys Info Button
Displays the satellite receiver System Information Screen

Page Down Button
Use to Page Down in the Program Guide or in the Themes List

Power Button
Turn On/Off the satellite receiver

Menu Button
Press to view the Main Menu

Guide Button
Displays the Program Guide and cycles through the Favorite Lists

Up Button
Channels up or Moves the cursor up

Right Button
Moves cursor to the Right

Down Button
Channels down or Moves the cursor down

Cancel Button
Cancels the screen currently displayed

View Button
View the Program Banner while watching programming

Number Buttons
Used to enter channel numbers, navigating the Interactive Menus

Recall Button
Returns to previous channel

Page Up Button
Use to Page Up in the Program Guide or in the Themes List

*** Only for applicable receivers**